WORLD SERIES FLOOR HF (HIGH FINISH)

FOR GOOD REFINEMENT (most common) the following two methods are recommended: From a World Series 60/80 metal tool, continue with: World Series Ceramic: 50> 100> 400 or World Series Ceramic: 80> 200> 400



Continue with the **WORLD SERIES 800 RESIN**. Alternatively, Luteues Pads. Two or more passes will produce the best result.



WORLD SERIES RESIN #800

See more on page: 26



Apply a guard product of choice , for example **SC**-



SC-SHINE

See more on page: 29



Polish the surface with a natural fiber pad **SCANPAD DANCER**, #1500.



SCANPAD DANCER, #1500

See more on page: 28

WORLD SERIES FLOOR VHF (VERY HIGH FINISH)

FOR MAXIMUM REFINEMENT, the following is recommended: From a World Series 60/80 metal tool, continue with: World Series Ceramics 50> 80> 100> 200> 400



Continue with the **WORLD SERIES 800 RESIN**. Alternatively, Luteues Pads. Two or more passes will produce the best result.



WORLD SERIES RESIN

See more on page: 26



Continue with the **WORLD SERIES RESIN #1500.** Two or more passes will produce the best result.



WORLD SERIES RESIN #1500

See more on page: 26



Apply a guard product of choice , for example **SC-SHINE**.



SC-SHINE

See more on page: 29



Polish the surface with a natural fiber pads, **SCANPAD DANCER**, **#1500**, followed by **#3000**.



SCANPAD DANCER #1500, #3000

See more on page: 28

